



Angled View



Front View

Pully Button



Optional Key

Releases the Alert Button



"Now, I have the assurance of knowing that if an intruder enters the building, I can [pull] the 'red button' and it alerts my colleagues."

Rena Mosely

Assistant
Ron Clark Academy, GA

The **Alert Notification Button** is similar to the Function button on the teardrop teacher microphone. By pressing the Alert Notification Button, it sends a message and activates the MS-1000 monitoring station, identifying the location and time the button was pulled. This optional Alert Notification Button can be strategically installed in additional locations (i.e. cafeterias, front offices, hallways, under desks, etc.).



Alert Notification Button Specifications

Weight	5.84 oz (165.56 g) mm)
Dimensions	3.5 (H) x 2.13 (W) x 1.25 (D) in. (88.9 x 54.1 x 31.75)

The SAFE System (patent pending) is an alert notification system not intended to be a life-saving device or prevent emergencies. Audio Enhancement, our agents, employees, subsidiaries, affiliates and parent companies are exempt from liability for any loss, damage, injury or other consequence arising directly or indirectly from the application of our equipment. In the event of misuse or malfunction of the SAFE System or any of its components, Audio Enhancement, our agents, employees, subsidiaries, affiliates and parent companies are exempt from liability for any loss, damage, injury or other consequence arising directly or indirectly therefrom.

SAFE System™
Compatible

